

## PREVENTATIVE MAINTENANCE 300 - 400 HOUR or 4,000 MILE INTERVAL

Date	Location	Inspector
Unit #	VIN	Tire Size
Year	Make	Model
Odometer Reading	Hour Meter	Annual DOT Inspection Due Date
<p>All inspections, adjustments, repairs, and lubrication must be performed in accordance with the manufacturer's recommendations and specifications. Refer to applicable manual.</p>		
<p>Cummins ISC &amp; ISB</p> <ul style="list-style-type: none"> <li>• Oil &amp; Oil Filter (300-400 hrs)</li> <li>• Fuel Filter (300-400 hrs)</li> <li>• Breather (60,000 Miles)</li> </ul> <p>Mercedes MBE 900</p> <ul style="list-style-type: none"> <li>• Oil &amp; Oil Filter (300 hrs)</li> <li>• Fuel Filter (300 hrs)</li> </ul> <p>International Maxforce, DT 466 &amp; 530</p> <ul style="list-style-type: none"> <li>• Oil &amp; Oil Filter (300 - 400 hrs)</li> <li>• Fuel Filter (300 - 400 hrs)</li> </ul> <p>Fuel/Water Separator Filters</p> <ul style="list-style-type: none"> <li>• Annually</li> </ul> <p>Anti-Freeze</p> <ul style="list-style-type: none"> <li>• Extended Life, check level - Change 5 yrs</li> </ul>		<p>Allison MD3060P, RDS 3000 and 3500 Filter &amp; Fluid (Non-synthetic Dextron)</p> <ul style="list-style-type: none"> <li>• 25,000 miles - 1000 Hrs - 12 mos Filter &amp; Fluid (Synthetic)</li> <li>• 75,000 miles - 3000 hrs - 36 mos</li> <li>• Prognostics - Wrench icon on shift selector</li> </ul> <p>Manual Transmissions</p> <ul style="list-style-type: none"> <li>• Non-synthetic (Interval)</li> <li>• Synthetic 300 hrs check level &amp; moisture</li> </ul> <p>Rear Axle</p> <ul style="list-style-type: none"> <li>• Non-Synthetic (Interval)</li> <li>• Synthetic 300 hrs check level &amp; moisture</li> </ul> <p>Air Dryer Filter/Cartridge</p> <ul style="list-style-type: none"> <li>• Annually</li> </ul>
<p>Miles/Hours    Service Operation</p> <p>_____ Change oil and check level</p> <p>_____ Change Fuel Filter</p> <p>_____ Change fuel/water separator filter</p> <p>_____ Check cooling system and test antifreeze</p> <p>_____ Change antifreeze (5 year interval)</p> <p>_____ Breather (if applicable) every 60,000 miles</p>	<p>Miles/Hours    Service Operation</p> <p>_____ Check transmission for moisture and level</p> <p>_____ Change transmission fluid and level</p> <p>_____ Check rear axle for moisture and level</p> <p>_____ Replace air dryer filter or cartridge</p>	
<p>Remarks:</p>		